

SHOWER and CUBICLE CURTAINS



Recommended Care

Sure-Chek healthcare fabrics offer "clean-in-place" convenience. Any soils or stains that may accumulate on the fabrics' surfaces should be removed periodically for a fresh new appearance. Use neutral soap suds and lukewarm water. Then rinse with water and allow fabric to dry.

Hard to Clean Spots: Standard household/vinyl cleansers and/or a soft bristle brush can be used for removing troublesome spots or stains. Heavy "dried on" soil may first require soaking to loosen. DO NOT USE HARSH CLEANSERS OR SOLVENTS.

Ocelco does not recommend the laundering of Sure-Chek healthcare fabrics since laundering may substantially decrease the useful life of these fabrics. However, if laundering is required, follow the procedures of the International Fabricare Institute:

1. Wash and rinse according to the "Synthetic Washing Procedure for Coated Fabrics" with temperatures not exceeding 100' F. (See below).
2. Extract water with centrifugal extractor.
3. Tumble dry in a steam dryer (not gas) at 120' F maximum. For tailored, precise fitted items, tumble dry without heat or air dry. DO NOT IRON.



Synthetic Washing Procedure for Coated Fabrics

(International Fabricare Institute Commercial Washroom Procedures)

Operation	Water Level	Time	Maximum Temperature	Supplies
1st Suds	High	5Min.	100°F	Neutral Soap & Alkali
2nd Suds	High	10 Min.	100°F	Neutral Soap & Alkali
1st Rinse	High	3Min.	100°F	Water
2nd Rinse	Low	3Min	90°F	Sour to pH 5.0

Use a slow speed machine. Stop the wash wheel for draining and refilling between each cycle.