

TR 1700

Height adjustable bathtub

Quick guide





1	Thermostatic mixing valve
2	Shower handle
3	Overflow and drainage locking
4	Aluminium actuator column
5	Adjustable feet
6	Hand control for height adjustment
7	Actuator

For further information see Operating manual

Working Load Limit: 150 kg (330 lbs)

