

# Clickeze EZE•Swap™ Cubicle Curtain Snap Panel System

---



- Standard fabric panels are 66" x 66", but are also available in custom sizes
- Continuous Mesh Panels are made to order to meet your specific project's needs
- Fabric Panels easily snap to each other to provide full privacy
- Easily snap curtain panels off of mesh without the use of a ladder
- Curtains have been tested and pass fire safety standards

# Clickeze EZE•Swap™ Cubicle Curtain Snap Panel System

## Suggested Specifications

---

### PART 1 – GENERAL

#### 1.01 SUMMARY

##### A. Privacy Curtain

#### 1.02 SECTION INCLUDES

##### A. EZE-Swap™ Cubicle Curtain Snap Panel System

#### 1.03 REFERENCES

##### A. National Fire Protection Association (NFPA)

#### 1.04 SYSTEM DESCRIPTION

##### A. Performance Requirements: Provide privacy curtains that conform to the following requirements of regulatory agencies and the quality control of Clickeze, InPro Corporation.

##### 1. Fire Performance Characteristics: Provide curtains that conform with NFPA 701, Fire Tests for Flame and Resistant Textiles and Films.

#### 1.05 SUBMITTALS

##### A. Product Data: Manufacturer's printed product data for each type of privacy curtain specified.

##### B. Fabric Samples: Swatch cards of fabric samples illustrating fabric color and weave.

##### C. Manufacturer's Care Instruction: Printed care instructions for each curtain.

#### 1.06 DELIVERY, STORAGE AND HANDLING

##### A. Deliver materials in unopened factory packaging to the jobsite.

##### B. Inspect materials at delivery to assure that specified products have been received.

##### C. Store in original packaging in a climate controlled location away from direct sunlight.

#### 1.07 PROJECT CONDITIONS

##### A. Environmental Requirements: Products must be installed in an interior climate controlled environment.

#### 1.08 WARRANTY

##### A. Standard Clickeze Limited Warranty against material and manufacturing defects.

### PART 2 – PRODUCTS

#### 2.01 MANUFACTURER

##### A. Acceptable Manufacturer Clickeze, InPro Corporation, PO Box 406 Muskego, WI 53150 USA;

Telephone: 800.222.5556,

Fax: 888.715.8407,

Internet address: [www.inprocorp.com](http://www.inprocorp.com)

##### B. Substitutions: Not permitted

##### C. Provide all privacy curtains from a single source.

#### 2.02 MATERIALS

##### A. Privacy Curtain

##### 1. Fabric: Provide 100% polyester curtains. Fabric is to be opaque, washable, flame retardant and closely woven.

##### 2. Shield Fabric: Provide 100% polyester, impregnated and multi-coated with Aqueous based microporous

polymers.

##### 3. EnviroGT Fabrics: Provide fabrics that contain Recycled Polyester or are made from 100% Eco Polyester. Eco polyester fabrics shall be free of chlorine and PBT's (persistent, bioaccumulative and/or toxic substances).

##### 4. Open Mesh Cloth: Provide curtain heading of open weave nylon mesh material with #50, 1/2" (12.7mm) holes to permit air and steam circulation. Mesh is to be flame retardant, washable and dry-cleanable.

##### 5. Grommets: Provide 4-ounce (113.4g) #2 nickel-plated grommets that are machined into top mesh hem or mesh header placed six (6") inches on center.

##### 6. Curtain Snaps:

##### a. Bottom Mesh Footer: Provide rustproof, nickel-plated brass snaps with off-white plastic cover spaced 4-1/2" on center and machined into bottom mesh footer.

##### b. Top Curtain Header: Provide rustproof, nickel-plated brass, double-sided snaps spaced 4-1/2" on center and machined into top curtain header.

#### 2.03 FINISH AND COLOR

##### A. Cubicle Privacy Fabric: Select solid or patterned fabric from manufacturer's standard selection.

##### B. Open Mesh Cloth: Provide curtain heading of mesh material in a color selected from manufacturer's standard selection.

#### 2.04 FABRICATION

##### A. Fabricate curtains to comply with the following requirements:

##### 1. Horizontal Width: Provide finished panel width of 66" horizontal, custom widths available upon request. Panel to be manufactured with 1-1/4" double turned hems on all four (4) sides. Along top horizontal width, double-sided snaps made of nickel-plated brass to be machined into fabric and set at 4-1/2" on center.

##### 2. Vertical Length: Provide finished panel vertical length of 66", custom lengths available upon request.

##### a. Bottom of privacy curtains hang 12"-15" (304.8-355.6mm) above finished floor. Height tolerance ±1".

##### 3. Mesh: Mesh to be manufactured in one horizontal continuous piece sized to be 10% wider than the track length but no less than 12" (304.8mm) extra fullness. Width tolerance ±3". Mesh height will vary to accommodate specific application or needs.

##### a. Bottom mesh hem to be single-turned and reinforced with webbed tape stitched with double needle lock stitch no less than 1-1/4" in width.

##### b. Side mesh hems to be double turned and stitched with double needle lock stitch no less than 1-1/4" in width.

##### c. Sewing Options

##### 1. Framing: Self curtain fabric sewn on all four (4) sides of mesh.

##### 2. Top Banding: Self curtain fabric sewn at mesh header

(where grommets are placed).

##### 3. Bottom Banding: Self curtain fabric sewn at mesh footer (where snaps are placed).

### PART 3 – EXECUTION

#### 3.01 EXAMINATION

##### A. Examine areas and conditions in which the cubicle tracking systems will be installed.

##### 1. Complete all finishing operations, including painting, before beginning installation of cubicle tracking system materials.

##### 2. Verify that surfaces and above ceiling supports are ready to receive work.

#### 3.02 PREPARATION

##### A. General: Prior to installation, clean substrate to remove dust, debris and loose particles.

#### 3.03 INSTALLATION

##### A. General: Locate the cubicle track as indicated on the approved detail drawing for the appropriate substrate and in compliance with the Clickeze installation instructions.

##### B. Installation of Cubicle Tracking Systems:

##### 1. Install cubicle track, secure, rigid, and true to ceiling line.

##### 2. Slide carriers onto the track.

##### 3. Install end cap or stop device.

##### 4. Secure or suspend track to ceiling system. Install with mechanical fasteners or Gridclips.

##### 5. Install curtains on carriers ensuring smooth operation.

#### 3.04 CLEANING

##### A. At completion of the installation, remove any debris and clean surfaces in accordance with the Clickeze clean-up and maintenance instructions.